

OCF Magnum Reflector Mounting instruction



 **Profoto**

About OCF Magnum Reflector

The OCF Magnum Reflector is designed with the on-location photographer in mind. Use it with your Profoto Off-Camera Flash to maximize your light while staying mobile.

By flipping through these pages you'll quickly learn how to get the most out of your new OCF Magnum Reflector.

Use restrictions and compatibility

Note!

The OCF Magnum Reflector is only recommended for Profoto Off-Camera Flashes and monolights with flat front. Max flash power: 1000Ws. Max modeling light: 300W.

OCF Magnum Reflector is recommended for:

- Profoto B1
- Profoto B1X
- Profoto B2
- Profoto B10 & B10 Plus
- Profoto B10X & B10X Plus
- Profoto D1
- Profoto D2

**Get started with
your new reflector**



- 1 Open the clasp on the rubber collar and gently push the reflector onto your light.



- 2 Before closing the clasp, adjust the light spread by sliding the reflector back and forth on the head.



- 3 Pull back the reflector for a wide light spread.



- 4 Push the reflector forward to gradually narrow the light spread and increase the light output.



- 5 Lock the reflector to your selected position by closing the clasp on the rubber collar.

The protective case

The included case protects your reflector during transport and storage. The adjustable strap makes it easy to attach onto other bags or backpacks.



 Profoto

 Profoto

**For more information and inspiration:
profoto.com**